B.C. Banes PTERANOD Assembly Instructions: 1. Lightly sand any edges with the fine sand paper which is enclosed in your kit. 2. Lay the B.C.Bones out to match the "Excavation Site Map" 3. Starting with slot 1, carefully interlock the B.C.Bones by matching numbers shown on the map. 4. Although some B.C.Bones appear to be the same, it is important to inter-lock the correct ones, paying careful attention to the legs and order of the ribs. 5. If B.C.Bones are too loose, use a small drop of white household glue. 6. When fully assembled, enjoy displaying your B.C.Bones dinosaur in your room or take it apart to build again, making sure to carefully retain all the B.C.Bones. 7. It is also fun to glue it all together or paint it using watercolor markers, paint or tempera paints. Refer to this B.C. Bones layout to insure the correct direction of key components as you follow the assembly instructions. COME VISIT US AT: WWW.bcbones.co